This file contains scalable dynamic blocks for our 3750 Series Folding Door. Here is how to use them:

1. Copy the desired block and paste it in your drawing.
2. Select the item and open the Properties tab.
3. At the bottom of the Properties tab you will see a Custom section. From there you can change the panel configuration and the width.


3.0.3 Outswing

Exterior
Panels not to scale

4.0.4 Outswing

Exterior
Panels not to scale

5.0.5 Outswing

Exterior
Panels not to scale

6.0.6 Outswing

Exterior
Panels not to scale

7.0.7 Outswing

Exterior
Panels not to scale

8.0.8 Outswing

Exterior
Panels not to scale

Project:	File name: 3750 Folding Door Configuration - Complete Series	Date: 20180402
Notes:	Layout: 3750 Configuration	Drawn by: J Johnson